

FINISH CARE & CLEANING

Proper care and cleaning are required to ensure the longevity of the Fixtures and to prevent voiding the Fixture warranty. The Fixtures are made mostly of acrylic, which is non-porous in nature, making it easy to clean. The acrylic may be cleaned with a soft cloth using mild soap and water, or one of the Recommended Cleaners listed below (use only the exact cleaner name listed). When using any cleaner, please follow the instructions on the label. Always thoroughly rinse any cleaning product immediately after cleaning, **taking care not to allow liquid to enter the lens compartment at either end of the fixture.** Do not allow cleaners to remain on the acrylic for an extended period of time. **Use only cleaning products labeled safe for acrylics.** Particular care should be taken to avoid abrasive materials and strong cleaning agents. Use of unapproved cleaning products will void the warranty and may cause damage to your acrylic in the form of scratching, crazing, discoloration and/or dulling of the surface.

RECOMMENDED CLEANERS

3M General Purpose Cleaner #8	Joy Detergent
3M Non-Acid Bathroom Cleaner #15	Kaboom Shower/Tub Cleaner
3M Hvy Duty Multi-Surface #2	Liquid Dish Soaps
Bathcrest Cleaner	Lysol All-Purpose Cleaner with Bleach
Calgon	Lysol Mildew Remover
Cascade	Mr. Clean
10% Clorox Bleach mixed with 90% water	Orange Goop
Ecolab All-Purpose Cleaner	Scrub Free
Fantastic All Purpose	Simple Green
Fantastic Lemon Power Antibacterial	Soft Scrub Gel w/Bleach
Fantastic Total Bathroom	Sparkling Orange
Formula 409 Orange Power	Tilex Fresh Shower
Gel Gloss	Tilex Mildew Remover
Glass Plus	Top Job
Grease Lightening	Vim Cream
Handy Andy	Vinegar & Water Mix
Hopes Perfect Glass	Windex Multi-Surface
Isopropanol (45%)	Windex with Vinegar
Janitor in a Drum	X-14 Orange Bathroom Cleaner